

# KoubaLink Installation Instructions

*Fits: 2014-up Suzuki DL1000 V-Strom. Lowers the rear 1 1/8"  
PN: V-Strom 14-2*

1) If your bike does not have a center stand raise the rear of the motorcycle with a jack under the engine so the rear wheel is just slightly off the ground. The best way is to tie the handle bars down to floor side mounts so the bike cannot tip over. Be careful where you put the jack and try to get it towards the rear of the engine so you are mainly lifting the rear. We use a wood 2 X 8 about 10" long on top of the jack. Remove the two 17 mm nuts from the link mounting bolts (both 14 mm headed mounting bolts come in from the left) that hold the stock link to the mounting brackets. Push both mounting bolts out the left side  
\*The swingarm may need to be raised slightly to allow the first bolt to slide out freely.

2) The new link comes with only the bearings and seals, so install the center sleeves from your OEM link into the new KoubaLink. Put some grease inside the KoubaLink bearings and also on the center sleeves before installing them in the KoubaLink. The grease fittings are non-functional on these as we had to use the OEM bearings which are solid including the seals. :- ( Install the KoubaLink by holding it up inside the front and rear mounting brackets with the grease fittings facing down, push the front mounting bolt in from the left side. You will have to raise the swingarm slightly to allow the rear link eye to align with mounting clevis eyes before pushing the rear mounting bolt in. Install the 17 mm nuts on the mounting bolts and torque to approx. 40 lbs-ft.

3) You can slide the fork tubes up (maximum 3/4" as anything more may allow the fender to come up and hit the triple clamps if the forks are bottomed) for additional lowering, but how much you need to slide them up will depend on the amount of rear race sag your running and how you prefer it to ride. Keep in mind that lowering the rear more than the front slows the steering but makes it more stable on the striates and visa versa.

**\*Disclaimer: Raising or lowering the rear more than the front can change the geometry and could affect the handling, so be careful out there.**

**If you like what the KoubaLinks do for your suspension, please tell everyone, if you do not, please tell us. We can be contacted at our e-mail address below and are always interested in your questions or comments.**