

KoubaLink Installation Instructions

Fits: 2021+ Yamaha Tenere 700

- 1) Raise the motorcycle with a bike stand, milk crate, etc., so the rear wheel is slightly off the ground. Remove the 17mm nuts from the right side of the linkage. Push the bolts through with your finger so the stock link is removed. You may have to raise/lower the rear wheel if the bolts seem "stuck"

- 2) Remove the center sleeves from where the bolts came through and make sure the bearings are greased and clean. Assembly grease or marine grease will work great.

- 3) Adjust the rear wheel up so the holes in the link align with the holes in the swingarm/frame. You may need another person to help raise/lower the rear wheel for easy alignment. Install the bolts and torque to factory specs.

- 4) The front fork tubes can be slid up in the triple clamps until they almost touch the stock handlebars, we do not recommend going farther than the stock height handlebars allow. If the front pushes or will not turn quick enough we recommend lessening the rear sag rather than sliding the fork tubes up farther.

Disclaimer: Lowering the rear more than the front can change the geometry and could affect the handling, so be careful out there.

If you like what the KoubaLink does for your suspension, please tell everyone, if you do not, please tell us!